


- 1 : Not used.
- 2..3 : ON-ON : Monochrome video.
 : OFF - ON : 50/60Hz multisync colour modes.
 : ON - OFF : 72Hz multisync colour
 : OFF - OFF : Legacy colour modes.
- 4 : ON : RAM = 14MB.
 : OFF : RAM = 4MB.
- 5 : ON : ACSI disabled.
 : OFF : ACSI enabled.
- 6 : ON : Flash base address = 0x00E0xxxx.
 : OFF : Flash base address = 0x00FCxxxx.



Configuration Switch X6